


Getting Started

- On-Board

On-Board		Using the keys on top of the Blue-Bot
----------	---	---------------------------------------

-Tactile Reader

Tactile Reader		Using the tactile reader remotely via Bluetooth
----------------	--	---

- Logo Software

Logo Software	<p>Welcome to Terrapin Logo</p> <pre>> bluebot? Result: TRUE > bluebot.run [forward 1 right 45] bluebot.run [forward 1 right 45 forward 2]</pre>	Use the Logo software and program the Blue-Bot via Bluetooth
---------------	--	--